
Unable to charge the battery pack.

When the battery pack is fully charged, the lamp does not flash.
If the terminal of this unit or the battery pack is dirty, wipe it with a cotton swab or something similar.
Using a non-original battery pack may result in damage to this unit. Be sure to use an original battery pack.