
The slider and operation buttons do not work.

Touch the slider and buttons around the screen with your fingers.
The slider and buttons do not function if you touch them with your fingernails or with gloves on.
The displays on the screen do not work even if you touch them.