## **Manual Recording**


You can adjust settings, such as brightness and shutter speed, by using the manual mode

Manual recording can be set for both video and still image modes.


 ${\it 1}$  Select video or still image mode.



- The video or still image mode icon appears.
- 2 Select the Manual recording mode.



- The mode changes between Auto and Manual with every touch.
- 3 Start recording.



• Press again to stop.

## NOTE:

• The manual settings are displayed only in the manual mode.

## **Manual Recording Menu**

The following items can be set

Name	Description
SCENE SE- LECT	Recordings that suit the shooting conditions can be performed easily.
FOCUS	Use manual focus if the subject is not focused automatically.
BRIGHTNESS ADJUST	<ul> <li>Overall brightness on the screen can be adjusted.</li> <li>Use this when recording in a dark or bright location.</li> </ul>
SHUTTER SPEED	Shutter speed can be adjusted.     Use this when shooting a fast-moving subject or to emphasize the subject's movement.
WHITE BAL- ANCE	Overall color on the screen can be adjusted.     Use this when the color on the screen appears differently from the actual color.
BACKLIGHT COMP.	Corrects the image when the subject appears dark due to backlight.     Use this when shooting against the light.
METERING AREA/ TYPE	Brightness of a specified area can be set as the standard.
EFFECT	Images that look like old photographs or black- and-white movies can be taken.
TELE MACRO	Use this to take close-up (macro) shots of the subject.