


Protecting All Files


Protects all files.

Memo :


To select/move cursor towards up/left or down/right, press the button UP/< or DOWN/>.




- 1 Select the playback mode.



- 2 Press MENU.



- 3 Select "PROTECT/CANCEL" and press OK.



- 4 Select "PROTECT ALL" and press OK.



- 5 Select "YES" and press OK.



- After setting, press OK.