


### Setting SMILE%/NAME DISPLAY

“SMILE%/NAME DISPLAY” allows you to set the items to display when faces are detected.


This item is only displayed when “TOUCH PRIORITY AE/AF” is set to “FACE TRACKING”.

- 1 Open the LCD monitor and select the video or still image mode.



- The video or still image mode icon appears.

- 2 Tap “MENU”.



- 3 Tap “SMILE%/NAME DISPLAY”.



- 4 Tap the desired setting.



Setting	Details
OFF	Displays only the frames when faces are detected.
ON	Displays the frames, names, and smile levels (%) when faces are detected.

- Frame: Appears around detected faces.
- Name: Appears for faces that are registered.
- Smile level: Appears in value (0 % - 100 %) for detected smiles.



### Memo :

- The camera is able to detect up to 16 faces. Smile levels will be displayed for up to 3 of the largest faces displayed on the screen.
- Some faces may not be detected depending on the shooting environment.
- You can register personal authentication information like face, name, and priority level of person before recording.
- Up to 3 registered names will be displayed according to the priority level.
- “SMILE%/NAME DISPLAY” is set to “ON” when the demo mode is activated.