

Creating Discs with a DVD Writer

You can copy the recorded files to discs or play back the created discs using an optional DVD writer.

Compatible DVD Writers

Product Name	Description
DVD Writer ● CU-VD3U	<ul style="list-style-type: none"> Enables the images recorded on this unit to be copied to a DVD without using a PC.
DVD Writer ● CU-VD50U	<ul style="list-style-type: none"> Creates DVDs and functions as an external DVD drive when connected to a PC. In addition, created DVDs can be played back by connecting the CU-VD50U to a TV.

Creating Discs with a DVD Writer

■ Preparing a DVD Writer

■ Copying to Discs

■ Other Operations


Memo :

- When there are many files to back up, it may take time for the backup to be completed. Wait for a while as the access lamp appears blinking, which indicates normal operation.
- Date and time information as saved as subtitles in the created discs.

Changing the Media of the DVD Writer

Set the type of media according to the loaded DVD.

- 1 Prepare a DVD writer.
- 2 Tap "CHANGE REC. MEDIA" in the "BACK-UP" menu.



- 3 Tap "DVD(AVCHD)" or "DVD-Video".



- The media changes to the tapped item. Select the appropriate setting according to the disc.
- Selecting "DVD(AVCHD)" enables you to save videos in a DVD in the high definition quality.
- Selecting "DVD-Video" enables you to save videos in a DVD after converting to the standard image quality.