


Deleting All Files

Deletes all files.


CAUTION:

- Deleted files cannot be restored.


1 Select the playback mode.



2 Select video or still image mode.




3 Touch to display the menu.



4 Select "DELETE" and touch .



5 Select "DELETE ALL" and touch .



6 Select "YES" and touch .



- After deleting, touch .

Memo:

- When files in a playlist are deleted, the playlist changes.
- Files that are protected cannot be deleted.
Release protection before deleting the file.