


Deleting All Files

Deletes all files.

Memo :


To select/move cursor towards up/left or down/right, press the button UP/< or DOWN/>.




Caution :

- Deleted files cannot be restored.


1 Select the playback mode.




2 Press MENU.




3 Select "DELETE" and press OK.



4 Select "DELETE ALL" and press OK.



5 Select "YES" and press OK.



- After deleting, press OK.
- To cancel the deletion, select "NO" and press OK.

Memo :

- Files that are protected cannot be deleted.
Release protection before deleting the file.