Backing Up Files Without Using Provided Software

Copy the files to a computer using the following method.

1 Open the LCD monitor.



2 Connect the USB cable and the AC adapter.



- 1 Connect using the provided USB cable.
- 2 Connect the AC adapter to this unit.
- This unit powers on automatically when the AC adapter is connected.
- Be sure to use the supplied JVC AC adapter. 3 The "SELECT DEVICE" menu appears.
- 3 Tap "CONNECT TO PC".



4 Tap "PLAYBACK ON PC".



- Tap \times to exit the menu.
- Tap 5 to return to the previous screen.
- Close the Everio MediaBrowser 3 program, if it starts.
- The subsequent operations are to be performed on the computer.
- 5 Select "Computer" (Windows Vista) / "My Computer" (Windows XP) / "Computer" (Windows 7) from the "Start" menu, then click on the "JVCCAM_MEM" or "JVCCAM_SD" icon.
 - Open the folder with the desired files.
 - "JVCCAM_MEM" is applicable to GZ-HM650/GZ-HM655 only.
- **6** Copy the files to any folder in the computer (desktop, etc).

Caution : -

• When the folders or files are deleted/moved/renamed in the computer, they cannot be played back on this unit anymore.

Memo :

- To edit/view the files, use a software that supports AVCHD (video)/JPEG (still image) files.
- The above operations on computer may vary with the system used.

Disconnecting this Unit from Computer

1 Click "Safely Remove Hardware and Eject Media".



- 2 Click "Safely Remove USB Mass Storage Device".
- 3 (For Windows Vista) Click "OK".
- 4 Disconnect the USB cable and close the LCD monitor.