

## Connecting to and Viewing on TV

You can connect this unit to a TV for playback. The image quality on TV varies with the type of TV and the connecting cable. Select the connector that best suits your TV.

- Refer also to the instruction manual of the TV in use.

### Unnatural Displays on TV

Trouble	Action
Images do not appear on the TV properly.	<ul style="list-style-type: none"><li>• Disconnect the cable and connect again.</li><li>• Turn off and on this unit again.</li></ul>
Images are projected vertically on the TV.	<ul style="list-style-type: none"><li>• Set "VIDEO OUTPUT" in the "COMMON" menu to "4:3".</li></ul>
Images are projected horizontally on the TV.	<ul style="list-style-type: none"><li>• Adjust the TV's screen accordingly.</li></ul>
The color of images looks strange.	<ul style="list-style-type: none"><li>• If the video was recorded with "x.v.Color" set to "ON", set the x.v.Color setting of the TV to on.</li><li>• Adjust the TV's screen accordingly.</li></ul>
HDMI-CEC functions do not work properly, and the TV does not work in conjunction with this unit.	<ul style="list-style-type: none"><li>• TVs may operate differently depending on the specifications, even if they are HDMI-CEC compliant. Therefore, the HDMI-CEC functions of this unit cannot be guaranteed to operate in combination with all the TVs. In such cases, set "HDMI CONTROL" to "OFF".</li></ul>
The language on the display changed.	<ul style="list-style-type: none"><li>• It may occur when you connect this unit to a TV with different language setting using an HDMI mini cable.</li></ul>