Releasing Protection of All Files

Releases protection of all files.

Select the playback mode.



2 Select video or still image mode.



3 Touch (m) to display the menu.



4 Select "EDIT" and touch .



5 Select "PROTECT/CANCEL" and touch @.



6 Select "CANCEL ALL" and touch .



7 Select "YES" and touch .



• After setting, touch ®.