


WIND CUT

Reduces the noise caused by wind.


Setting	Details
OFF	Deactivates the function.
ON	Activates the function.

Displaying the Item

- 1 Select video mode.



- 2 Touch to display the menu.



- 3 Select "WIND CUT" and touch .

