


## DATE DISPLAY STYLE

Sets the order of year, month, day and the time display format (24H/12H).

- 1 Touch to display the menu.



- 2 Select "DISPLAY SETTINGS" and touch .



- 3 Select "DATE DISPLAY STYLE" and touch .






- 4 Set the style of date and time display.



- For date display, set to any format from "month.day.year", "year.month.day", and "day.month.year".
- For time display, set to any format from "12h" and "24h".
- Touch the operation buttons "←" / "→" to move the cursor.
- After setting, touch .

## Clock Set Style

The clock set style of this unit varies with the models.



- The order of "Year, Month, Day, Time" changes according to the date display style.