DATA DELETION ERROR (GZ-MS230 only)

Check the operating procedure, and perform once again.
"ERASE ALL DATA (GZ-MS230)" （☞ P. 0 ）
Turn off this unit, and turn it on again.

DATA DELETION ERROR (GZ-MS230 only)

Check the operating procedure, and perform once again.
"ERASE ALL DATA (GZ-MS230)" （☞ P. 0 ）
Turn off this unit, and turn it on again.