NO FILES

Change the setting of "REC MEDIA FOR IMAGE", "REC MEDIA FOR
VIDEO", "REC VIDEO TO SLOTS", or "REC STILLS TO SLOTS" in the
"COMMON" menu, and check that files are not recorded to the other media.

NO FILES

Change the setting of "REC MEDIA FOR IMAGE", "REC MEDIA FOR
VIDEO", "REC VIDEO TO SLOTS", or "REC STILLS TO SLOTS" in the
"COMMON" menu, and check that files are not recorded to the other media.