

-

-

-

-
- The screenshot shows the iMovie application window. The 'Titles' menu is open, displaying several title options. The 'Titles' menu is located in the top-left corner of the iMovie window. The 'Titles' menu is open, showing a list of title options. The 'Titles' menu is open, showing a list of title options. The 'Titles' menu is open, showing a list of title options.

7

Ajustes de menú

SALIDA HDMI	Ajusta la definición de la salida de vídeo desde el mini conector HDMI.
CONTROL HDMI	Ajusta las operaciones de ON/OFF cuando el TV y esta unidad están conectados con un mini conector HDMI.
CONFIG. DE FÁBRICA	Regresa todos los ajustes a los valores predeterminados.
ACTUALIZAR	Actualiza las funciones de esta unidad a la última versión.
ACTUAL. SOFTWARE PC	Actualiza el software de PC incluido de esta unidad a la última versión.
FORMATEAR MEM INT	Elimina todos los archivos de la memoria integrada.
FORMATEAR TARJETA SD	Elimina todos los archivos de la tarjeta SD.
BORAR MEM INTEGRADA	Ejecute este proceso si se va a deshacer de esta unidad o si se la da a otra persona.