**Cannot insert the SD card.**

Make sure not to insert the card in the wrong direction.

**Cannot insert the SD card.**

Make sure not to insert the card in the wrong direction.