Manual Recording

You can adjust settings, such as brightness and shutter speed, by using the manual mode.
Manual recording can be set for both video and still image modes.

*1* Select video or still image mode.

● The video or still image mode icon appears.

2 Select the Manual recording mode.

● The mode changes between Auto and Manual with every touch.

3 Start recording.

● Press again to stop.

Memo:
● The manual settings are displayed only in the manual mode.

Manual Recording Menu

The following items can be set.

Name	Description
SCENE SELECT	● Recordings that suit the shooting conditions can be performed easily.
FOCUS	● Use manual focus if the subject is not focused automatically.
FOCUS ASSIST	● Use this for adjusting the focus more precisely.
BRIGHTNESS ADJUST	● Overall brightness on the screen can be adjusted. ● Use this when recording in a dark or bright location.
SHUTTER SPEED (GZ-HD620)	● Shutter speed can be adjusted. ● Use this when shooting a fast-moving subject or to emphasize the subject's movement.
WHITE BALANCE	● Overall color on the screen can be adjusted. ● Use this when the color on the screen appears differently from the actual color.
BACKLIGHT COMP.	● Corrects the image when the subject appears dark due to backlight. ● Use this when shooting against the light.
METERING AREA/TYPE	● Brightness of a specified area can be set as the standard.
EFFECT	● Images that look like old photographs or black-and-white movies can be taken.
TELE MACRO	● Use this to take close-up (macro) shots of the subject.