ON-SCREEN DISPLAY

Sets whether to show on-screen displays such as icons during playback.

Setting	Details
OFF	No display at all.
DISPLAY ALL	Displays everything.
DISPLAY DATE ONLY	Displays the date only.

Displaying the Item

*1* Select the playback mode.

2 Select still image mode.

3 Touch ⓜ to display the menu.

4 Select "ON-SCREEN DISPLAY" and touch ⓚ.