

Adjusting Brightness

You can adjust the brightness to your preferred level.

1 Touch **☺** to display the menu.



2 Select "MANUAL SETTING" and touch **☺**.



3 Select "BRIGHTNESS ADJUST" and touch **☺**.



4 Select "MANUAL" and touch **☺**.



5 Select the brightness value with the slider.



- Compensation range during video recording: -6 to +6
- Compensation range during still image recording: -2.0 to +2.0
- Slide upward to increase the brightness.
- Slide downward to decrease the brightness.

6 Touch **☺** to confirm.



NOTE:

- Settings can be adjusted separately for videos and still images.