Digital zoom does not work.

Digital zoom is not available in the still image recording mode. Zoom operation is not available in time-lapse shooting. (Simultaneous still image recording and DIS are also not available.) To use digital zoom, set"ZOOM"in the menu to"90x/DIGITAL" or "800x/ DIGITAL".