

### Copying Selected Files

Select and copy the desired videos.

1 Select "SELECT AND CREATE" and touch **OK**.



2 Select the media for copying and touch **OK**.



3 Select "SELECT FROM SCENES" and touch **OK**.



4 Select the desired video and touch **OK**.



- A check mark appears on the selected video. To remove the check mark, touch **OK**.
- Touch "CHECK" to check the video.

5 After selecting, touch "SAVE".



6 Select "ALL" and touch **OK**.



- The number of discs required to copy the files is displayed. Prepare the discs accordingly.
- Touch "CHECK" to check the file to copy.

7 Select YES or NO and touch **OK**.



- When "YES" is selected, videos with similar recording dates are displayed in groups.
- When "NO" is selected, videos are displayed according to recording dates.

8 Select "EXECUTE" and touch **OK**.



- When "INSERT NEXT DISC" appears, change the disc.

9 After copying, touch **OK**.



10 Close the LCD monitor, then disconnect the USB cable.

**CAUTION:**

- Do not turn off the power or remove the USB cable until copying is complete.
- Files that are not on the index screen during playback cannot be copied.

**NOTE:**

- To check the created disc, select "PLAYBACK" in step 1.