

## Creating Multiple Discs

You can create multiple discs of the same content.

1 Select "CREATE DUPLICATE" and touch **OK**.



2 Select the media for copying and touch **OK**.



• The media for copying varies with the model.

3 Select the date of creation from the creation history and touch **OK**.



• Touch "CHECK" to check the file to copy.

4 Select "EXECUTE" and touch **OK**.



• When "INSERT NEXT DISC" appears, change the disc.

5 After copying, touch **OK**.



6 Close the LCD monitor, then disconnect the USB cable.

### CAUTION:

- Do not turn off the power or remove the USB cable until copying is complete.
- Files that are not on the index screen during playback cannot be copied.

### NOTE:

- To check the created disc, select "PLAYBACK" in step 1.
- Up to 20 of the newest data can be stored in the creation history.