Moving Selected Files

Moves selected videos and still images to another media. Files that are moved will be deleted from the original media.

1 Select the playback mode.



2 Select video or still image mode.



 ${\it 3}$ Touch ${\it le m}$ to display the menu.



4 Select "EDIT" and touch ®.



5 Select "MOVE" and touch @.



6 Select the direction of moving and touch @.



7 Select "SELECT AND MOVE" and touch @.



8 Select the desired file and touch @.



- A check mark appears on the selected file.

 To remove the check mark, touch

 again.
- 9 After selecting all the files to move, touch EXEC.



10 Select "YES" and touch .



- Moving of files starts.
- After moving, touch @.