

## DATA DELETION ERROR

Check the operating procedure, and perform once again.  
Turn off the camcorder, and turn it on again.