SHUTTER MODE

Continuous shooting settings can be adjusted.

Setting	Details
RECORD ONE SHOT	Records one still image.
CONTINU- OUS SHOOTING	Records still images continuously while the SNAPSHOT button is pressed.

NOTE:-

- Up to 3 images can be captured in 1 second during continuous shooting.
- Some SD cards may not support continuous shooting.
- The continuous shooting speed will drop if this function is used repeatedly.

Displaying the Item

1 Select still image mode.



2 Touch $\ensuremath{ ext{@}}$ to display the menu.



 $\it 3$ Select "SHUTTER MODE" and touch $\it ext{@s}$.

