

Copying Selected Playlists

Arrange and copy the created playlists in the order you like.

1 Select "SELECT AND CREATE" and touch .



2 Select the media for copying and touch .



3 Select "CREATE BY PLAYLIST" and touch .



4 Select the desired playlist and touch .



• Touch "CHECK" to check the selected playlist.

5 Select the insertion point and touch .



- The selected videos are added to the playlist on the right.
- To delete a video from the playlist, touch "→" to select the video and touch .
- Repeat steps 4-5 and arrange the videos in the playlist.

6 After arranging, touch "SAVE".



7 Select "ALL" and touch .



- The number of discs required to copy the files is displayed. Prepare the discs accordingly.
- Touch "CHECK" to check the file to copy.

8 Select "EXECUTE" and touch .



- When "INSERT NEXT DISC" appears, change the disc.

9 After copying, touch .



10 Close the LCD monitor, then disconnect the USB cable.

CAUTION:

- Do not turn off the power or remove the USB cable until copying is complete.
- Files that are not on the index screen during playback cannot be copied.

NOTE:

- A list of playlists is displayed on the top menu of the created DVD.
- To check the created disc, select "PLAYBACK" in step 1.
- To create a playlist