

---

**Unable to charge the battery pack.**

When the battery pack is fully charged, the lamp does not flash.  
If the terminal of this unit or the battery pack is dirty, wipe it with a cotton swab or something similar.  
Using a non-original battery pack may result in damage to this unit. Be sure to use an original battery pack.