


Zooming

The shooting range can be adjusted using zoom.

- Use the W end (wide angle end) to shoot a wider field of view.
- Use the T end (telephoto end) to magnify the subject for shooting.



- You can also use the slider's T/W zoom to zoom.



NOTE:

- Digital zoom is not available in the still image recording mode.