
Unable to create DVD with a DVD writer.

The USB cable is not connected correctly.

If the provided software Everio MediaBrowser is not installed, some functions may not work properly.

Use a PC that supports DVD-R/RW.