

## Search Date

You can search and play videos or still images according to recording dates.

- The contents of the saving destination selected in “REC MEDIA FOR VIDEO” or “REC MEDIA FOR IMAGE” are searched.
- Still images can only be searched by “SEARCH DATE”.

1 Display the search function.




- You can also display the search menu by selecting “SEARCH” on the playback menu. For still images, select “SEARCH DATE” on the menu.
- Searching can be performed in both the video and still image modes.  
\*The image shows the video mode.

2 Select “SEARCH DATE” and touch **OK**.



3 Select a recording date and touch **OK**.



- The starting day of the week on the calendar switches between Sunday and Monday with every touch of the  button.

4 Select the desired video or still image and touch **OK** to start playback.



- You can select videos in the video mode and still images in the still image mode.
- Only the videos recorded on the selected date are displayed.

Deleting Files of a Selected Date : \_\_\_\_\_  
 Select “DELETE” from the playback menu to delete unwanted files. \_\_\_\_\_