




**SELF-TIMER**


Use this when taking a group photo.


Setting	Details
OFF	Deactivates the self-timer.
2SEC	Starts recording 2 seconds after the SNAPSHOT button is pressed.
10SEC	Starts recording 10 seconds after the SNAPSHOT button is pressed. This setting is suitable for taking group photos.
FACE-DETECTION	<p>Detects faces when the SNAPSHOT button is pressed. Recording starts 3 seconds after the face of the photographer is detected.</p> <p>(1) Faces are detected</p>  <p>(2) Face of photographer is detected</p> <p>Photographer</p> 

**Displaying the Item**

1 Select still image mode.



2 Touch  to display the menu.



3 Select "SELF-TIMER" and touch .

