

---

**Digital zoom does not work.**

Digital zoom is not available in the still image recording mode.  
Zoom operation is not available in time-lapse shooting. (Simultaneous still image recording and image stabilizer are also not available.)  
To use digital zoom, set "ZOOM" in the menu to "60x", "80x", or "200x".