


REC MEDIA FOR IMAGE

Sets the recording/playback media of still images.

| Setting | Details |
|---------|---|
| HDD | Records still images to this unit's HDD. |
| SD | Records still images to the microSD card. |

Displaying the Item

1 Touch  to display the menu.



2 Select "MEDIA SETTINGS" and touch .



3 Select "REC MEDIA FOR IMAGE" and touch .

