

## Playback Menu (Still Image)

You can delete or look for specific still images.

Setting	Details
DELETE	Deletes unwanted still images.
SEARCH DATE	You can search and play still images according to recording dates.
EDIT	<ul style="list-style-type: none"><li>• COPY Copies files to another media.</li><li>• MOVE Moves files to another media.</li><li>• PROTECT/CANCEL Protects files from being deleted accidentally.</li></ul>
SLIDE SHOW EFFECTS	Effects can be added to the transitions in slideshow playback.
ON-SCREEN DISPLAY	Sets whether to show on-screen displays such as icons during playback.