Releasing Protection of All Files

Releases protection of all files.

 ${\it 1}$ Select the playback mode.



2 Select video or still image mode.



 $\it 3$ Touch $\tiny \textcircled{\tiny m}$ to display the menu.



4 Select "EDIT" and touch ®.



5 Select "PROTECT/CANCEL" and touch @s.



6 Select "CANCEL ALL" and touch os.



7 Select "YES" and touch ®.



• After setting, touch .