


Copying Files by Date

Files are sorted and copied according to the date on which they were recorded.

1 Select video or still image mode.




2 Select "SELECT AND CREATE"/"SELECT AND SAVE" and touch **OK**.




3 Select the media for copying and touch **OK**.



4 Select "CREATE BY DATE"/"SAVE BY DATE" and touch **OK**.



5 Select the desired recording date and touch **OK**.




6 Select "EXECUTE" and touch **OK**.



- The number of discs required to copy the files is displayed. Prepare the discs accordingly.

- Touch "CHECK" to check the file to copy.

7 Select "YES" or "NO" and touch **OK**. (M mode only)



- When "YES" is selected, videos with similar recording dates are displayed in groups.
- When "NO" is selected, videos are displayed according to recording dates.

8 Select "EXECUTE" and touch **OK**.



- When "INSERT NEXT DISC" appears, change the disc.
- After copying, touch **OK**.

9 Close the LCD monitor, then disconnect the USB cable.

CAUTION:

- Do not turn off the power or remove the USB cable until copying is complete.
- Files that are not on the index screen during playback cannot be copied.