Cannot insert the microSD card.

Make sure not to insert the card in the wrong direction.