


Bottom

- 1** Tripod Mounting Hole
- 2** microSD Card Slot
 - Insert an optional microSD card.
- 3** Battery Release Lever
- 4** Battery Mount