



## Protecting Selected Files

Protects or releases protection of the selected files.


1 Select the playback mode.



2 Select video or still image mode.



3 Touch to display the menu.



4 Select "EDIT" and touch .



5 Select "PROTECT/CANCEL" and touch .



6 Select "FILE SELECT" and touch .



7 Select the desired file and touch .



• A mark appears on the selected file.

To remove the mark, touch again.

• Touch "CHECK" to check the selected file.

8 After selecting all the files to protect or release protection of, touch .



9 Select "YES" and touch .

