


## Copying Selected Playlists (video mode only)

Arrange and copy the created playlists in the order you like.

1 Select video mode.



2 Select "SELECT AND CREATE" and touch **OK**.



3 Select the media for copying and touch **OK**.



4 Select "CREATE BY PLAYLIST" and touch **OK**.



5 Select the desired videos and touch **OK**.



• Touch "CHECK" to check the selected video.

6 Select the insertion point and touch **OK**.



- The selected videos are added to the playlist on the right.
- To delete a video from the playlist, touch "→" to select the video and touch **OK**.
- Repeat steps 5-6 and arrange the videos in the playlist.

7 After arranging, touch "SAVE".



- The positions of the "←"/"→" and "SAVE" operation buttons may change according to the position of the cursor.

8 Select "EXECUTE" and touch **OK**.



- The number of discs required to copy the files is displayed. Prepare the discs accordingly.
- Touch "CHECK" to check the file to copy.

9 Touch **OK**.



10 Select "EXECUTE" and touch **OK**.



- When "INSERT NEXT DISC" appears, change the disc.
- After copying, touch **OK**.

11 Close the LCD monitor, then disconnect the USB cable.

### CAUTION:

- Do not turn off the power or remove the USB cable until copying is complete.
- Files that are not on the index screen during playback cannot be copied.

### NOTE:

- A list of playlists is displayed on the top menu of the created DVD.
- To create a playlist