
## Interior



## 1 Speaker

- Outputs audio sound during video playback.
- 2 ▶ (Play) Button
- Switches between the recording and playback modes.
- 3 ≝ / 🗖 (Video/Still Image) Button
- Switches between video and still image.
- 4 UPLOAD/EXPORT\* (Upload/Export to iTunes\*) Button
- Recording: Takes videos in YouTube™ or iTunes\* format.
- Playback: Changes the video to YouTube™ or iTunes\* format. (\*GZ-HD620 only)
- 5 **齿** (Power/Info) Button
- Recording: Displays the remaining time (for video only) and battery power.
- Playback: Displays file information such as recording date.
- Press and hold to turn the power on/off while the LCD monitor is opened.
- 6 AV Terminal
- Connects to a TV.
- 7 COMPONENT Terminal
- Connects to a TV.
- 8 HDMI Terminal
- Connects to an HDMI TV.