# Registering Files to Events Before Recording

Videos can be found easily during playback by categorizing them when recording.

1 Select video mode.

2 Touch ⊛ to display the menu.

3 Select "REGISTER EVENT" and touch ⊛.

4 Select the event type and touch ⊛.

Event Type
VACATION
HOLIDAY
SPORTS
ANNIVERSARY
CONGRATULATIONS
BABY
SON
DAUGHTER
BIRTHDAY
GRADUATION

● An icon appears on the screen and the video is recorded under the selected event.
(Videos will continue to be recorded to the same event until a change is made.)

NOTE:

● To cancel event registration, touch "CANCEL" in step 4.

● The registered event can be changed again later.