



## Protecting All Files

Protects all files.


1 Select the playback mode.



2 Press MENU to display the menu.




3 Select "PROTECT/CANCEL" with the ZOOM/SELECT lever and press OK.



4 Select "PROTECT ALL" and press OK.



5 Select "YES" and press OK.



- After setting, press OK.