



Protecting All Files

Protects all files.


- 1 Select the playback mode.




- 2 Press MENU to display the menu.



- 3 Select "PROTECT/CANCEL" with the ZOOM/SELECT lever and press OK.



- 4 Select "PROTECT ALL" and press OK.



- 5 Select "YES" and press OK.



- After setting, press OK.