


Manual Recording


You can adjust settings, such as brightness and shutter speed, by using the manual mode.

1 Select the Manual recording mode.



- The mode changes between Auto and Manual with every press.

2 Start recording.



- Press again to stop.

Memo:

- The manual settings are displayed only in the manual mode.

Manual Recording Menu

The following items can be set.

| Name | Description |
|--------------------|---|
| SCENE SELECT | <ul style="list-style-type: none">• Recordings that suit the shooting conditions can be performed easily. |
| FOCUS | <ul style="list-style-type: none">• Use manual focus if the subject is not focused automatically. |
| BRIGHTNESS ADJUST | <ul style="list-style-type: none">• Overall brightness on the screen can be adjusted.• Use this when recording in a dark or bright location. |
| SHUTTER SPEED | <ul style="list-style-type: none">• Shutter speed can be adjusted.• Use this when shooting a fast-moving subject or to emphasize the subject's movement. |
| WHITE BALANCE | <ul style="list-style-type: none">• Overall color on the screen can be adjusted.• Use this when the color on the screen appears differently from the actual color. |
| BACKLIGHT COMP. | <ul style="list-style-type: none">• Corrects the image when the subject appears dark due to backlight.• Use this when shooting against the light. |
| METERING AREA/TYPE | <ul style="list-style-type: none">• Brightness of a specified area can be set as the standard. |
| TELE MACRO | <ul style="list-style-type: none">• Use this to take close-up (macro) shots of the subject. |