

INSUFFICIENT AVAILABLE SPACE

Delete files, or move files to a PC or other devices.
Replace the SD card with a new one.