
Recording cannot be performed.

Set to the recording mode with the  (Play) Button.