


Interior



1 Speaker

- Outputs audio sound during video playback.

2 (Play) Button

- Switches between the recording and playback modes.

3 / (Recording Mode) / + Button

- During recording: Switches the recording mode (Auto/Manual).
- During playback: Increases the volume.

4 INFO (Information)/ - Button

- During recording: Displays the remaining time and battery power.
- During playback: Decreases the volume.
- During playback: Displays file information such as recording date.

5 MENU Button


- Displays the settings menu.

6 AV Terminal

- Connects to a TV.

7 LCD Monitor

- Turns the power on/off by opening and closing.
- Enables self-portraits to be taken by rotating the monitor.



CAUTION:

- Do not press against the surface with force or subject it to strong impact.
Doing so may damage or break the screen.