


Playing Back Videos

You can select and play back the recorded videos from an index screen (thumbnail display).

1 Select the playback mode.



2 Select the desired video with the ZOOM/SELECT lever and press OK to start playback.



- You can also press the START/STOP button to start playback.
- Press the OK or START/STOP button to stop (pause) playback.
- To return to the index screen, slide along the ZOOM/SELECT lever while paused.

Operations During Video Playback

Operation Button	Operation
 OK START /STOP 	Playback/pause
	Forward search/reverse search
	Volume adjustment

Memo:

- You can search for a specific file by the recording date. This is useful when searching from a large number of files.

CAUTION:

- Make a backup of important recorded data
It is recommended to copy your important recorded data to a DVD or other recording media for storage. JVC will not be responsible for any lost data.

Checking the Recording Date and Other Information

Press the INFO button when the index screen is displayed or while paused.

